

DMX Channel Chart (White) :

CH MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
9CH	dimming	strobe	macroefficiency	speed of macroefficiency	level motor	vertical motor	speed of level motor	speed of vertical motor	reset										
19CH	dimming	strobe	head 1 white dimming	head 2 white dimming	head 3 white dimming	head 4 white dimming	macroefficiency of 4 head	macroefficiency speed of 4 head	head 1 level motor	head 1 vertical motor	head 2 level motor	head 2 vertical motor	head 3 level motor	head 3 vertical motor	head 4 level motor	head 4 vertical motor	speed of level motor	speed of vertical motor	reset