

DMX Channel Chart ( RGBW ) :

CH MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
14CH	dimming	strobe	red dimming	green dimming	blue dimming	white dimming	colour mixture	macroefficiency	macroefficiency speed	level motor	vertical motor	level motor speed	vertical motor speed	reset					
32CH	dimming	strobe	head 1 R dimming	head 1 G dimming	head 1 B dimming	head 1 W dimming	head 2 R dimming	head 2 G dimming	head 2 B dimming	head 2 W dimming	head 3 R dimming	head 3 G dimming	head 3 B dimming	head 3 W dimming	head 4 R dimming	head 4 G dimming	head 4 B dimming	head 4 W dimming	color mixture of 4 heads
	20	21	22	23	24	25	26	27	28	29	30	31	32						
	macroefficiency of 4 heads	macroefficiency speed of 4 heads	head 1 level motor	head 1 vertical motor	head 2 level motor	head 2 vertical motor	head 3 level motor	head 3 vertical motor	head 4 level motor	head 4 vertical motor	speed of level motor	speed of vertical motor	reset						